


= MAIN =
32" x 26"
A IC 800
FLI8532
(CORTEZ)
B

= INITIAL (32") =
JACK_BD
MP DATA (8-1DR)

APPLIED MODEL
32LX2R, 32LP1R, 37LP1R, 42LP1R





= JACK_BD =
26" ONLY
LP & MP PCB DATA

SIDE_COMP


TORNADO
INITIAL-32
LX TOOL ALSO
USE THIS CIRCUIT

LP TOOL FINAL




INDEX
TORNADO [ML-051A]
32LP1R-ZE

LED ASSY



KEY_FRONT
TORNADO
INITIAL_32INCH




LP TOOL FINAL

LOGO BD


FOR TORNADO
32INCH

LP TOOL FINAL



IR BOARD


32LP1R-ZE
TORNADO



IR_LOGO BD
FOR TORNADO

32.26 LX TOOL

MODIFY FOR LP



KEY BD
FOR TORNADO

32.26 LX TOOL

MODIFY FOR LP

